

Cleaning and disinfection machine TOPIC.2

Short Operating Instructions



Display

Indicates warnings, errors or maintenance information.

Indicator lamp

Program key normal program

Program key intensive program for heavy contamination

Program key Short program, only for utensils with urine

Rim flushing (for separate slop sink) Option: Wash chamber rinsing

Fault display for warnings or errors

Confirmation key acknowledges errors / switches the signal off

Cursor field Keys ▲ ▼ for the number of program cycles,

Keys ◀ ▶ see full version of
Operating Instructions

